



Scan the QR code to download "iCam365" APP

## A Connect the device

**Download the app**

Use the "Scan" function of your mobile phone to scan the QR code, download and install the "iCam365" APP

**Connect power**

Connect the device to the power supply and wait for about 1 minute

## B Add device

App will be updated continuously, and the interface is subject to App

01.log in

02.Add device

03.Select WIFI Camera

04.Choose an add method  
This demo Selects Quick Add

05.Follow the prompts.  
When you hear the tone should be checked,Chick Next

06.Select a device nearby

07.Enter the password

08.Select the WiFi to connect to and enter the password

09.Waiting to configure the network

10.The addition is complete,the device is named

## C Function Description

App will be updated continuously, and the interface is subject to App

Alarm message

Display mode

Live and playback

Settings

Share the device

More features

Intelligent Recognition

Cloud recording

Settings

More settings

Sound switch

Recording screen

Screenshot

Video clarity

Full screen

Card playback

Cloud playback

Direction control

Intercom

## D Common problem

Problems	Solution
What should I do if the device is unsuccessfully added?	Check whether the WiFi password is correct, and the network can be connected correctly, then RESET the camera, and add it again after completion.
How to download video?	1.Tap the screen recording icon "📹" while viewing the playback. 2.Click the stop button "■" when finished. The video is automatically saved to the phone album.
What if the display device is offline?	First confirm whether the power supply and network are normal, and there is no problem before powering off the camera and restarting it. If the connection is still disconnected
The memory card is full, what should I do?	No manual processing is required. When the remaining memory card capacity is less than or equal to 500M, the camera will automatically overwrite the oldest video file.
The memory card shows no memory card or abnormal	1. The camera does not support hot swapping. When inserting a memory card, it needs to be powered off. Please restart the camera.2. The memory card is still not recognized after restarting the camera, please replace with a new card and test again.3. If the new card is still not recognized, the card slot may be damaged or the cable is faulty. Contact the supplier to replace the device.
What should I do if I cannot receive the warning message?	Confirm whether the system has turned off the message push permission of iCam365. If it is turned off, please turn on the "message notification" permission in the phone settings and check whether the message push is turned off in the device settings. Alarm messages are stored for up to 7 days